



VISION FOR LIFE

Telemedicine Over-bed Cameras

NETS recommends the following Telemedicine device to support the delivery of remote neonatal and paediatric specialist expertise to clinical teams across NSW:

PANASONIC WV-S6131

Full-HD PTZ dome Network Camera

40x iA (intelligent Auto) H.265 PTZ Camera



More information here: https://security.panasonic.com/products_technology/products/wv-s6131/

Key Contact: Matthew.Terrey@au.panasonic.com

Please Note: Panasonic do not supply direct to market however, they will assist with your requirements and connect the Local Health District with a suitable supplier or contractor.

This solution does not require a wall switch although the installer could add this into the design should the department wish to continue with the push button activation.

The device requires one Ethernet cable for power and connectivity (POE), where possible, cabling should be done by the Local Health District to reduce costs.

A new State-wide interface is being developed by eHealth NSW, which will provide comprehensive usage reports for Local Health Districts.

Telehealth and web conferencing solutions such as Skype for Business, Pexip, and Zoom are not fit-for-purpose to deliver remote specialist expertise to clinicians who are dealing with an emergency case.

The following installation options are available:

[Embedded Ceiling Mount](#) – click to expand

For recessing the camera into the ceiling, this requires approximately 190mm of space above the ceiling tiles in order to recess the camera.

For mounting the cameras directly to ceiling tiles, particularly soft ones, it's recommended to have a lightweight wooden panel placed on top of the tile for the camera to be screwed to, effectively sandwiching the ceiling tile. The installer should fit a safe wire (as they did at NETS) from the wood panel to the concrete slab above for safety support purposes. The cameras are exceptionally light in comparison to the old Sony solution and take up far less real estate within the department than the Cisco video conference based systems.

[Privacy Smoked Dome Cover](#) – click to expand

Dependant on the sensitivity of cameras in some locations, this cover somewhat hides the head of the camera so that people are not aware of exactly where it is looking.

A test device is available for trial within the NETS Simulation Room:

Test Device: <http://10.202.10.250/>

Username: netscontrol

Password: N3ts2020



Should you require any assistance please contact:

Graeme Still, Telemedicine Lead | t +61 2 9633 8804 | m +61 4 09 462 591

e vfl@NETS.health.nsw.gov.au